

# NECESSARY CAUTIONS AND CAVEATS

Use only with Shinola Diffuser Oil Blend. Burn time of the included tealight is four hours.

Use on a flat, stable surface that resists or tolerates heat, away from draughts. Keep away from curtains, and any other flammable objects. Keep out of reach of children and pets. Do not leave unattended while in use.

Use only standard-sized unscented tealight candles in a protective casing. Do not re-light tealight until wax completely solidifies. Discontinue use of tealight when only a quarter amount of wax remains or if candle begins to sputter.

**The Oil Diffuser, particularly the metal lid, will become hot during use. Allow to cool before handling.**

# CARE AND KEEPING

The brass metal lid may be cleaned with warm water and a mild dish soap. Avoid using abrasive cleaners. Rinse and dry thoroughly before next use. For a deeper clean, use a homemade blend of flour, salt, and white vinegar, or a blend of lemon juice and baking soda. Avoid using store-bought cleaners that may have fragrance added.

The ceramic vessel may be cleaned with a soft cloth to remove debris and dust.